

Tips for fitting the Adjustable Rebated Butt Hinge

This is a repair hinge to allow you to be able to replace the old type rebate door hinges which are no longer made in the 9 mm and 11 mm axis critical dimensions. If you use the frame part of the hinge as the datum point, you should be able to create a successful repair.

Using the three pre-drilled screw holes on the existing outer frame you will find that the repair hinge should be able to be screwed into place on the outer frame. Please note that you will also need to drill two holes for the fixing pins also on the repair hinge which were not on the old existing frame hinge. Once done the new hinge will fit in situ. You will then set the opening door sash part of the hinge up to sit round the door sash (adjusting it to wrap round snugly by spinning the plate round and if necessary adjusting the Allen key setting (make sure all the new hinges are set up to the same settings).

Lastly screw the said plate into the groove within the door and ensure the screws are firmly fixed in place. Once done lift the door sash back onto the hinges and fix both parts together using the long hinge pins to do so. If necessary you can use the Allen key to make final adjustments to either slacken or tighten the door sash against the outer frame. place the hinge cover caps over to finish the installation.