


Garden Cart

Instruction Manual

Thank you for purchasing our **Garden Cart**. Please read through these instructions before proceeding with the assembly of this product. Please ensure that the carton contains all the parts required.

Operation of tilt mechanism



Tipping the plastic tray
On the lock mechanism pull the handle to release the lock and lift upwards.

Lowering the plastic tray
Slowly push the plastic tray down. Pull the handle and release back into the locating holes on (D/E).



Garden Cart Parts

Please ensure that you have all the parts listed below before proceeding with the assembly of this product.

- A** 75 Litre plastic tray (x1)
 - B** Rear chassis (x1)
 - C** Rear axle (x1)
 - D** Front chassis (x1)
 - E** Front axle/steering (x1)
 - F** Rear support (x1)
 - G** Rear support (x1)
 - H** Lock mechanism (x1)
 - I** Inflatable wheel (x4)
 - J** Handle (x1)
- | | | |
|--------------------------------------|---|----------------------------------|
| a x2
25mm hex head bolts | b x14
24mm round head bolts | c x17
15mm locking nut |
| d x17
16mm washers | e x4
19mm locking nut | f x4
24mm washers |
| g x1
65mm round head bolts | ASSEMBLY REQUIRES
1 PERSON | |

Tools required for assembly: Large flat head screwdriver; large cross head screwdriver; adjustable spanner or socket set.

1

Place the plastic tray (A) upside down onto a flat surface ready to begin the assembly process.

2

Place the rear chassis (B) onto the plastic tray (A) and align the holes.

3

Attach the rear axle (C) to the plastic tray (A) with the rear chassis (B) inbetween using 2x bolts (b), 2x washers (d) and 2x nuts (c).

4

Attach the front axle/steering (E) to the front chassis (D) by using 4x bolts (a), 4x washers (d) and 4x nuts (c).

5

Attach the front axle/and front chassis (D/E) at an angle as shown above to the rear chassis (B) with 2x nuts (d), 2x bolts (b) and 2x washers (c).

6

Slot the rear supports, parts (F) and (G) over the axle pole of part (C) then attach to tray (A) with the rear chassis (B) in between using 4x bolts (b), 4x washers (d) and 4x nuts (c).

7

Attach the lock mechanism (H) to the front chassis/front axle (D/E) using 4x bolts (b), 4x washers (d) and 4x nuts (c). 2x on the top and 2x on the front.

8

Attach 1x Wheel (I) to one of the axles on either part (C) as shown above.

9

Attach the remaining 3 wheels (I) in the same way that the first wheel (I) was attached in step 8.

10

Attach the handle (J) using nut (c), washer (d) and bolt (g) to part (D/E) as shown above.

11

Whilst still upside down, ensure that all the nuts and bolts are secure before turning over and using.

12

The garden cart is now complete and ready for use.

WARNING! - MAX LOAD CAPACITY : 120KG